



- ① slide canvas holder assembly off of easel
- ② turn canvas holder assembly around and slide back on easel
- ③ (pull ring up on bottom canvas holder and slide until it clicks)
- ④ loosen knobs on sides and stand easel up (keeping base flat) then re-tighten knobs